

Service Bulletin ALN161 Retain for future use. Rev. B, 10/14/13

L-849 (L) A/E (REIL) FAA Baffle Installation Procedure KIT 94A0658



Disclaimer

This manual could contain technical inaccuracies or typographical errors. ADB Airfield Solutions reserves the right to revise this manual from time to time in the contents thereof without obligation of ADB Airfield Solutions to notify any person of such revision or change.

Details and values given in this manual have been compiled with care. They are not binding, however, and ADB Airfield Solutions disclaims any liability for damages or detriments suffered as a result of reliance on the information given herein or the use of products, processes or equipment to which this manual refers. No warranty is made that the use of the information or of the products, processes or equipment to which this manual refers will not infringe any third party's patents or rights.

Warranties

Products of ADB Airfield Solutions manufacturer are guaranteed against mechanical, electrical, and physical defects (excluding lamps) for a period of one year from the date of installation or a maximum of 18 months from date of shipment and are guaranteed to be merchantable and fit for the ordinary purposes for which such products are made.

ADB Airfield Solutions will correct by repair or replacement, at its option, equipment or parts which fail because of mechanical, electrical or physical defects, provided that the goods have been properly handled and stored prior to installation, properly installed and properly operated after installation, and provided further that Buyer gives ADB Airfield Solutions written notice of such defects after delivery of the goods to Buyer. Refer to the Safety section for more information on Material Handling Precautions and Storage precautions that must be followed.

ADB Airfield Solutions reserves the right to examine goods upon which a claim is made. Said goods must be presented in the same condition as when the defect therein was discovered. ADB Airfield Solutions furthers reserves the right to require the return of such goods to establish any claim.

ADB Airfield Solutions' obligation under this guarantee is limited to making repair or replacement within a reasonable time after receipt of such written notice and does not include any other costs such as the cost of removal of defective part, installation of repaired product, labor or consequential damages of any kind, the exclusive remedy being to require such new parts to be furnished.

ADB Airfield Solutions' liability under no circumstances will exceed the contract price of goods claimed to be defective. Any returns under this guarantee are to be on a transportation charges prepaid basis. For products not manufactured by, but sold by ADB Airfield Solutions, warranty is limited to that extended by the original manufacturer.

This is ADB Airfield Solutions' sole guarantee and warranty with respect to the goods; there are no express warranties or warranties of fitness for any particular purpose or any implied warranties of fitness for any particular purpose or any implied warranties other than those made expressly herein. All such warranties being expressly disclaimed.

Trademarks

General notice: other product names used here are for identification purposes only and may be trademarks of their respective companies.

Proprietary Information

This information carrier contains proprietary information, which shall not be used for other purposes than those for which it has been released, nor be reproduced or disclosed to third parties without the prior written consent of ADB Airfield Solutions.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopy, recording, or otherwise, without the prior written permission of ADB Airfield Solutions. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

ADB Airfield Solutions shall not be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product. ADB Airfield Solutions shall not be liable against any damages arising from the use of any options or parts other than those designated as approved products. Copyright © 2010 by ADB Airfield Solutions. All rights reserved.

1.0 REIL Baffle Kit

This bulletin describes the field installation procedure to attach FAA style baffle assembly to the L-849 REIL housing. The baffles are designed to meet the requirements for REIL baffles assemblies as described in FAA Advisory Circular, AC 150/5340-30, Section 7.4 (b).

The baffles are designed to cut-off the top portion of the light beam. The baffles are not adjustable. See AC 150/5340-30, Figure 78 for the proper aiming and layout of the REILs.

This section contains general safety instructions for installing and using ADB Airfield Solutions equipment. Some safety instructions may not apply to the equipment in this manual. Task- and equipment-specific warnings are included in other sections of this manual where appropriate.

1.1 Safety

1.1.1 To use this equipment safely:

WARNING



Read installation instructions in their entirety before starting installation.

- Refer to the FAA Advisory Circular AC 150/5340-26, Maintenance of Airport Visual Aids Facilities, for instructions on safety precautions.
- Observe all safety regulations. To avoid injuries, always disconnect power before making any wiring connections or touching any parts. Refer to FAA Advisory Circular AC 150/5340-26.
- Become familiar with the general safety instructions in this section of the manual before installing, operating, maintaining or repairing this equipment.
- Read and carefully follow the instructions throughout this manual for performing specific tasks and working with specific equipment.
- · Make this manual available to personnel installing, operating, maintaining or repairing this equipment.
- Follow all applicable safety procedures required by your company, industry standards and government
 or other regulatory agencies.
- Install all electrical connections to local code.
- Use only electrical wire of sufficient gauge and insulation to handle the rated current demand. All wiring must meet local codes.
- Route electrical wiring along a protected path. Make sure they will not be damaged by moving equipment.
- · Protect components from damage, wear, and harsh environment conditions.
- · Allow ample room for maintenance, panel accessibility, and cover removal.
- · Protect equipment with safety devices as specified by applicable safety regulations.
- If safety devices must be removed for installation, install them immediately after the work is completed
 and check them for proper functioning prior to returning power to the circuit.

1.1.1.1 Additional Reference Materials:

- NFPA 70B, Electrical Equipment Maintenance.
- NFPA 70E, Electrical Safety Requirements for Employee Workplaces.
- ANSI/NFPA 79, Electrical Standards for Metalworking Machine Tools.
- OSHA 29 CFR, Part 1910, Occupational Health and Safety Standards.
- National and local electrical codes and standards.

1.1.2 Qualified Personnel

The term **qualified personnel** is defined here as individuals who thoroughly understand the equipment and its safe operation, maintenance and repair. Qualified personnel are physically capable of performing the required tasks, familiar with all relevant safety rules and regulations and have been trained to safely install, operate, maintain and repair the equipment. It is the responsibility of the company operating this equipment to ensure that its personnel meet these requirements.


Always use required personal protective equipment (PPE) and follow safe electrical work practices.

1.2 REIL Baffle Kit

Special Tools And Equipment Required (not supplied):

- · Small standard screwdriver
- Socket for #8-32 hex head nut
- · Ratchet for #8-32 hex head socket
- Electric or Air drill
- 3/16 drill bit

Figure 1: Baffle Kits



1.2.1 A/E REIL Baffle Kit

Retrofit Kit 94A0658 contains the following components:

Part Number	Description	Quantity
94A0658 /1	L-849 REIL BAFFLE ASSY - RIGHT SIDE ¹	1
94A0658 /2	L-849 REIL BAFFLE ASSY - LEFT SIDE ¹	1
64A0191/20	8-32 X 1-1/4" PAN HD PHIL	6
65A0043/3	RIVET 1/8" X 3/16" TO 5/16"	48
66A0015/15	#8 FLATWASHER	6
66A0026/15	#8 SPLIT LOCKWASHER	6
66A0323	SS ROUND SPACER #8 ID X 1/4 OD X 1/2 LONG	6

Both baffles must be installed on the REIL assemblies.

1.2.1.1 Assembly Steps:



WARNING

- Disconnect and lock out electrical power.
- Remove all power to L-849 before attempting to make any modifications.
- 1. No additional holes must be drilled in to the flange. The right, center and left top holes are already in the flange and is ready to use. Locate the three mounting holes on top and the bottom as shown in Figure 2. Remove the 3 screws, split washers from the top and the 3 screws, split washers from the bottom and retain for future use.

NOTE: The baffle fins are slanted with the low end of the fin pointing toward the center line of the runway. Therefore there is a LEFT (94A0658/2) and RIGHT (94A0658/1) hand baffle assembly. Left and Right is as viewed by the pilot on approach.

- 2. Attach the #8 large sealing washer, the spacer to the front of the REIL.
- 3. Insert REIL assembly into baffle assembly as shown in Figure 3 aligning mounting holes (Figure 2 and Figure 3) in flashing head assembly with left, center and, right spacers. Attach with the #8-32 x 1-1/4" large pan head screws, the #8 split lock washers and #8 flat washers as shown in Figure 3.
- 4. Assembly is complete. Repeat procedure for the other baffle.

NOTE: Any deviations from the above instructions will void the warranty.

RE-USE LG OD #8 SEALING WASHER.




Figure 2: Hole Location in REIL Assembly

Figure 3: Baffle and REIL Assembly





Figure 4: Baffle and REIL Assembly



Registered office:

ADB Airfield Solutions LLC 977 Gahanna Parkway Columbus, OH 43230

USA

Phone: +1 (614) 8611 304 Fax: +1 (614) 8642 069

Other addresses:

ADB Airfield Solutions Ltd. 5500 North Service Road, Suite 1108 Burlington, Ontario L7L 6W6

Canada

Phone: +1 (905) 331 6887 Fax: +1 (905) 331 9389

ADB Airfield Technologies Ltd. 01A Unit, 9F, LSH Plaza

8, Wangjing JieChaoyang DistrictBeijing 100102P.R. China

Phone: +86 10 8476 0106 Fax: +86 10 8476 0090

ADB N.V.

Dubai Silicon Oasis Wing D - Office D-309 P.O. Box 341218 United Arab Emirates Phone: + 971 4372 4970 Fax: + 971 4372 4975

ADB N.V./S.A.

39/47 Boulevard Ornano 93200 Saint-Denis France

Phone: +33 (1) 4922 9250 Fax: +33 (1) 4922 9255

ADB Airfield Solutions GmbH & Co. KG

Von-der-Tannstr. 31 90439 Nürnberg Germany

Phone: +49 (911) 9239 1287 Fax:+49 (911) 2852 582

ADB N.V.

Asia Pacific Regional HQ Unit C-9.3.1, Level 9, Block C Mines Waterfront Business Park

No. 3, Jalan Tasik
The Mines Resort City

43300 Seri Kembangan Selangor

Malaysia

Phone: +603 8941 4868 Fax: +603 8942 4869

ADB Airfield Solutions Netherlands

Prinses Beatrixlaan 614

Office D3.14 2595 BM Den Haag The Netherlands

Phone: +31 (0)70 304 3611 Fax: +31 (0)70 333 8094

ADB Airfield Solutions, Ltd. 2nd Floor, 3 Rivonia Village

Cnr Mutual Road and Rivonia Boulevard

South Rivonia 2128 South Africa

Phone: +27 (11)234 6768 Fax: +27 (11)234 6739 ADB

Unit 44, Business Innovation Centre

Binley Business Park Harry Weston Road Coventry, CV3 2TX United kingdom

Phone: +44 (0)1455 883130 Fax: +44 (0)1455 883179

ADB

Airfield Solutions Leuvensesteenweg 585 B-1930 Zaventem

Belgium

Phone: +32 (2) 722 17 11 Fax: +32 (2) 722 17 64 info.adb@adb-air.com www.adb-air.com

