

# APPROACH LIGHTING

## ALSF

### High-Intensity Approach Lighting System WITH ELEVATED SEQUENCED FLASHERS



#### Compliance with Standards

- FAA:** Designed according to ALSF-1, ALSF-2, ALSF-2/SSALR FAA-E-2628; FAA-E-2325 (Sequenced Flashing Components)
- ICAO:** Annex 14 para. 5.3.4.7, 5.3.4.15, 5.3.4.16, 5.3.4.30, and 5.3.4.31
- Military:** AFMAN(I) 32-1187/TM 811-5 (UFC 3-535-01) Approach Applications

#### Uses

ALSF-1, ALSF-2, and ALSF-2/SSALR approach lighting systems with elevated sequenced flashing lights are used at airports and military air bases to provide landing approach guidance, such as runway alignment, height perception, horizontal reference, and roll guidance extending from the landing threshold outward (2,400-3,000 feet) into the approach zone.

#### ALSF-1

- The ALSF-1 approach lighting system is used on Category I Instrument Landing Systems (ILS) and includes up to 24 light stations (100-foot spacing) with up to 22 centerline bars of steady-burning lights (five lights to a bar) and up to 15 flashers.

#### ALSF-2

- The ALSF-2 approach lighting system is used on Category II runways and includes up to 30 light stations (100-foot spacing) with 30 centerline bars of steady-burning lights (five lights to a bar) and up to 21 flashers.

#### ALSF-2/SSALR

- The SSALR approach lighting system has up to eight sequenced flashing lights and is used as part of a dual-mode approach lighting system (ALSF-2/SSALR) when Category I conditions exist on Category II designated runways.

#### Operating Conditions

Temperature: -67 °C to +137 °C (-55 °F to +55 °F)  
Humidity: 0 to 100%  
Altitude: 0 to 10,000 ft (3048 m) maximum

#### Theory of Operation

ADB Safegate's sequenced-flasher lighting systems include a master control unit, junction boxes, individual control cabinets (ICC), and elevated flasher units. In the ALSF configuration, an array of light bars are installed symmetrically around the centerline of the approach lighting system, starting at the approach threshold and extending a total distance of 2,400 feet (731.5 m) outward into the approach zone up to 3,000 feet (914 m) at facilities where high-speed military aircraft share runway usage. Up to 21 flashing lamp assemblies are installed in the outer portion of the approach lighting system at regular intervals. Flashing lights are arranged and connected in such a way as to produce a sequenced flashing light signal that has the appearance of a ball of light traveling down the system from the outer end (flasher farthest from the runway threshold) to the flasher assembly closest to the runway threshold.

**Note:** Steady-burning portion of ALSF system is ordered separately. See ADB Safegate PAR-56 data sheet 1042 for more details.

# APPROACH LIGHTING

## ALSF

### Master Control Cabinet

The master control cabinet contains control circuitry and monitoring PCBs, which provide the power, timing signals, misfire monitoring circuitry, and three-step intensity control signals to the sequenced flasher assemblies in remote (120 VAC or +48 VDC control) and local mode. The master cabinet can control up to 21 sequenced flasher assemblies, providing power and trigger signals to produce a sequenced flashing light signal having the appearance of a ball of light traveling down the approach zone.



### Master Control Cabinet

#### Flashers

- 1 - 8 flashers (maximum)
- 2 - 15 flashers (maximum)
- 3 - 21 flashers (maximum)

#### Monitoring

- 1 - Without monitoring
- 2 - With Monitoring (standard)

#### Voltage

- 1 - 120/240 VAC (standard)
- 2 - 480 VAC

#### Enclosure Type

- 1 - Standard
- 2 - Stainless steel

44D1650 - X X X X



### Packaging Information

Voltage	Dimensions	Gross Weight
120/240 VAC (standard)	37.25 x 30 x 11.38 in 94.6 x 76.2 x 28.9 cm	137 lb 62 kg
480 VAC	48 x 36 x 16.38 in 125.1 x 91.4 x 41.6 cm	279 lb 126.6 kg

### Master Control Cabinet Equipment Data


Input and Output Voltage	120/240 VAC, +10%, 60 Hz, three-wire, Voltage single-phase (neutral center-tapped). Optional input: 480 VAC, +10%, 60 Hz, two-wire, single-phase.
Output Trigger Pulses	Time-synchronized with the 60 Hz line
Time from Trigger Pulse to Trigger Pulse	In ALSF mode, corresponds to one cycle of 60 Hz line, 16.67 ms. In SSALR mode, corresponds to every other cycle of the 60 Hz line or 33.3 ms.
Modes of Operation	Manual (local) control and remote control (+48 VDC or 120 VAC)
Enclosure	NEMA 4, outdoor and ventilated (to prevent condensation)
Maintenance Features on Control Cabinet	<ul style="list-style-type: none"> <li>• Rotary control switch for manual control of brightness level of system</li> <li>• Flasher ON/OFF switch to de-energize flashers (if desired) when the approach lights are energized</li> <li>• LED indicators on control panel for system monitoring</li> <li>• Service entrance switch disconnects incoming power to the control unit</li> <li>• 100 W maintenance light</li> <li>• Door can be locked in a 120° open position</li> </ul>
Lightning Protection	Rugged surge protection on all input and output electrical connections

### Master Control Cabinet Input Power Requirements

Voltage	Maximum Number of Flashers	Maximum Power Requirements
120/240 VAC	3	4 kVA
	6	5 kVA
	9	6 kVA
	12	7 kVA
	15	8 kVA
	18	9 kVA
480 VAC	21	10 kVA
	12	7.5 kVA
	21	11 kVA

## Individual Control Cabinet (ICC)

Each flasher unit is controlled by an individual control cabinet, which houses triggering circuits, terminal blocks, and lightning arrestors. A safety interlock switch is incorporated into the enclosure to discharge the high-voltage circuitry when the cabinet door is opened.



### ICC Ordering Code

#### Flasher Type

- 1 = Elevated Flasher
- 3 = Elevated Flasher Panel Only
- 5 = Elevated Flasher (Stainless Steel)

44D1651 - X

### Junction Box

Junction boxes are used to distribute power and control signals to the ICCs. One junction box is required for each sequenced flasher in the system. Each junction box has two terminal strips to accommodate the incoming and outgoing power, control circuit, and monitoring wire for the flasher unit.



### Junction Box Ordering Code

- Standard Enclosure
- Stainless Steel Enclosure

44D1653  
44D1653-1

## ICC Equipment Data

Quantity	One for each flash unit
Enclosure	Outdoor, door handle can be padlocked
Input Voltage	120/240 VAC, 60 Hz, three-wire, (neutral center-tapped). Voltage range for operation is 185-260 VAC.
Input Current	1 A in high intensity (average)
Flash Lamp Output Voltage	+2,000 VDC
Maximum Power Consumption	250 W or less
Intensity Step Change Component Life	150,000 operations minimum
Protection	Rugged surge protection on all external wiring connections
Mounting	Two 2-inch (5.08 cm) threaded fittings are provided on bottom of cabinet for mounting. Mounting lugs are also provided on the back of the cabinet.
Installation Distance	ICC can be installed a maximum of 2,400 ft (370 m) from master control cabinet. Contact ADB for distances over 2,400 ft.
Dimensions	20 x 16 x 8 in (50.8 x 40.64 x 20.3 cm)
Weight	57 lb (25.85 kg)

## Junction Box Equipment Data

Quantity	One for each flasher unit
Conduit Hub	Two 2-inch hubs in the bottom of the box
Dimensions	14 x 14 x 6 in (35.56 x 35.56 x 15.24 cm)
Weight	15 lb (6.8 kg)

# APPROACH LIGHTING

## ALSF

### Elevated Flasher

Each elevated flash head assembly consists of a flashing light head, which houses a PAR-56 flashtube and a trigger transformer. A safety interlock switch is incorporated in the flash head. It works in conjunction with the individual control cabinet (ICC) interlock switch to discharge the voltage across the flash lamp when either the ICC door is opened or the flash-tube is removed.



#### Flash Head Ordering Code

44D1677 - X

#### Slip Fit

- 1 = Slip fitting for 2-inch EMT, 1.5-inch tube and tower
- 2 = Slip fitting for 1.5-inch Schedule 40 pipe and 62B0064 frangible coupling only

**Note:** Flash head includes lamp

### Elevated Flasher Equipment Data

Input Voltage	+2,000 VDC
Lamp	PAR-56 xenon flashtube
Lamp Life	Average 1,000 hours on high-intensity step
Intensity Decrease	30% or less over minimum rated lamp life
Flash Duration	40-100 microseconds
Flash Skipping	Less than 1% with no consecutive skipping
Light Beam Axis	Adjustable vertically from the horizontal to 25° above the horizontal
Vibration	Withstands vibration in frequency range of 10 to 2,000 Hz in accordance with NEMA Standard FA1-3.01
Enclosure	Rain tight
Mounting	On a 2-in (5.08 cm) frangible coupling or 2-in EMT conduit, or 1.5-inch (3.81 cm) OD tube or 1.5-inch schedule 40 pipe. Mounting can be on a 1-in (2.54 cm) pipe (used on an aluminum tower) using adapter sleeve.
Installation Distance	A maximum of 60 ft (18.3 m) from ICC
Dimensions	13.33 x 6.25 x 8.31 in (33.86 x 15.88 x 21.11 cm)
Weight	4 lb (1.8 kg)

### Elevated Flasher Photometric Data

Intensity Setting	Flash-Tube Intensity	
	Max. Effective Intensity	Min. Effective Intensity
High	20,000 cd	8,000 cd
Medium	2,000 cd	800 cd
Low	450 cd	150 cd

### In-pavement Flasher

In-pavement flashers are not available with this system. If in-pavement flashers are required, see the 400V Low-Voltage ALSF/MALSR system data sheet 2091.

**Flasher Tester**

The portable flasher tester is equipped with a test cable and plug, which connect to a socket in the ICC to monitor the operation of the flasher light unit. The flasher tester is capable of testing the power circuits and control signals from the primary control unit to the ICC, and from the ICC to the flash head.




**Flasher Tester Ordering Code** 44D1686 - 1

**Flasher Tester Equipment Data**

Contains	Voltmeter, pulse detector, test-signal switch, and intensity- and trigger-control switches
Test Cable	Plugs into socket in the ICC
Dimensions	9 x 17 x 10 in (22.9 x 43.2 x 25.4 cm)
Weight	3.5 lb (1.59 kg)

**Aiming Device**

The aiming device is used to adjust and measure the vertical elevation angle of PAR-38 and PAR-56 steady burning or flashing lamp holders. The aiming device permits aiming of the lamp axis perpendicular to the plane of the cover glass at any angle from 0° to +25° above the horizontal, even when mounted on low impact-resistant structures conforming to FAA-E-2604 or FAA-E-2702. The aiming angle is indicated on a scale calibrated in 1° intervals, and the actual aiming angle of the lamp holder with the aiming device attached is accurate to within ±0.5°.



**Aiming Device Ordering Code** 44D1654 - X

**Lamp Application**

- 1 = For PAR-56 Lamp Only
- 2 = For PAR-56 and PAR-38 Lamps

**Aiming Device Equipment Data**

Quantity	One
Aiming	Flash lamp axis can be aimed from 0° to 25° above the horizontal
Scale	Calibrated in 1° increments
Accuracy	±0.5°
Dimensions	7 dia. x 10 H in (17.78 dia. x 25.4 H cm)

# APPROACH LIGHTING

## ALSF

### Spare Parts Trunk

Spare Parts Trunk includes I/O interface, Control PCB, ICC Flasher PCB, Bleeder, and Monitoring PCBs.



### Spare Parts Trunk

#### Monitoring

- 1 = Flasher With Monitoring (Standard)
- 2 = Flasher Without Monitoring

#### Frequency

- 1 = 60 Hz

#### Flashers

- 1 = 8 Flashers (Maximum) System
- 2 = 15 Flashers (Maximum) System
- 3 = 21 Flashers (Maximum) System

#### Notes

- The spare parts trunk must be ordered separately for FAA-E-2628 applications
- Sequenced flashing components (Part No. 44A1788) are ETL Certified according to FAA-E-2325

44D1652 - X 1 X 0



### FAA ALSF Ordering Information

The above equipment is supplied for the ALSF-1, ALSF-2, and ALSF-2/SSALR approach lighting systems per FAA-E-2628.

Quantity	Description
1	Master Control Cabinet
Up to 21	Flashing Light Heads
Up to 21	Individual Control Cabinets
Up to 21	Junction Boxes
1	Aiming Device
1	Flasher Tester
1	Instruction Manual

**Note:** Additional equipment may be required, but must be ordered separately:

- PAR-56 Lamp Holder Assemblies
- PAR-56 Lamps
- Frangible Couplings
- Low Impact-Resistant Structures
- High-Voltage Interconnection Wire
- Spare Parts Trunk
- L-830 Isolation Transformer
- 1,500 W, 20 A/20 A, Isolation Transformer
- For in-pavement FAA-E-2952 ALSF high intensity system applications, see our IAML in-pavement approach light data sheet 2029 for details.

### High-Voltage Wire

Used to interconnect elevated flash head and individual control cabinet. Wire is supplied in 500-foot spools only. Please specify total length (in feet) of wire required when ordering.

High-Voltage Wire Ordering Code 12 AWG, 3 kV

89A0110-1

[www.adbsafegate.com](http://www.adbsafegate.com)